

Getting Started

The Imaging Source FireWire Telescope Cameras


Quick start

- First of all, connect the camera with the computer and insert the CD please
- First of all install the **Camera Driver**
- After that please install **IC Capture TIS**

Setup with a checklist

The material you need

- The components which have been delivered by The Imaging Source (telescope camera, FireWire cable, CD)
- PC or Laptop with PIII/800 MHz/256 MB or higher
- A 6-pin FireWire interface.
- A C-mount adapter for your telescope



Important: The Imaging Source FireWire Telescope Cameras get their power via the FireWire interface. In case of desktop PCs the power supply is ensured in any case.

Please note that in case of laptops, the interface card can also supply the camera with power. Usually, you will need to connect an external PSU to the FireWire interface card in order to power the connected camera.

If the laptop is equipped with a 4-pin FireWire interface, the power supply is feed in via a FireWire hub.



Interface cards, special cables, power supplies and hubs are provided by accessories dealers.

Please make sure that you have

- setup Windows 2000/SP4 or Windows XP/SP2
- a graphics card with 24 or 32 bit
- setup DirectX 9.0c or higher
- setup a 6-pin FireWire interface
- connected the camera to this interface

Software installation

Important: When you first connect the camera to your PC's IEEE 1394 interface, Microsoft Windows automatically installs a generic driver. This driver must not be used. Instead, please follow these steps to install The Imaging Source driver:

- Please insert the included CD and click
 - (1) **Install Camera Driver** (please follow the Driver Installation Wizard's dialog) and
 - (2) **Install IC Capture.AS** (please follow the Driver Installation Wizard's dialog). During the installation you will be asked to enter a serial number. Please find it on the CD's envelope.



EUROPEAN HEADQUARTERS
The Imaging Source Europe GmbH
Sommerstrasse 36,
D-28215 Bremen,
Germany

US HEADQUARTERS
The Imaging Source, LLC
7257 Pineville-Matthews Road,
Charlotte, NC 28226

www.astronomycameras.com

All product and company names in this document may be trademarks and tradenames of their respective owners and are hereby acknowledged.

The Imaging Source Europe GmbH cannot and does not take any responsibility or liability for any information contained in this document. The source code presented in this document is exclusively used for didactic purposes. The Imaging Source does not assume any kind of warranty expressed or implied, resulting from the use of the content of this document or the source code.

The Imaging Source Company reserves the right to make changes in specifications, function or design at any time and without prior notice.

Last update: August 2006
Copyright © 2006 The Imaging Source Europe GmbH
All rights reserved. Reprint, also in parts, only allowed with permission of The Imaging Source Europe GmbH.

All weights and dimensions are approximate.